

TemBreak² MCCB Accessories Code List (suitable for Front Conn & Standard Plug-in type [PMC] connection)

MODEL	SHUNT TRIP (AC240V)	UVT (AC415V)	AUX SW	ALM SW	BREAKER MTD HANDLE (TFJ & HB TYPE)	DOOR MTD HANDLE (SHAFT) (XFH, HP & HS TYPE)
E100SF	2H1929BBAK	2H1941BABK & UXUB0015AK (controller)	UXXB0001AK AUX & ALM combined Sw UXLB0008CK	UXLB0006AK	TFJ21XHU2	XFHA1V-TM T1HS10XF5BPNAPS083
S125SF/E160SF S160SCF/S160SF	T2SH00LA20WB	T2UV00LA40NWB	T2AX00LML3SWB	T2AL00LML3SWB	T2HB16LUR3BA	T2HP16LR5BTA T2HS16LF5BPNAPS083A
E250SF / S250SF					T2HB25LUR3BA	T2HP25LR5BTA T2HS25LF5BPNAPS083A
S100NF / S125NF S100GF / S125GF S125NJ / S125GJ	T2SH00A20WA	T2UV00A40NWA	T2AX00M3SWA	T2AL00M3SWA	T2HB12UR3BNA	T2HP12R5BNAPS4A T2HS12F5BPNAPS083A
S225NF / S250NF S225GF / S250GF S125RF/J / S225RF/J S250NJ / S250GJ H125NJ / H250NJ					T2HB25UR3BNA	T2HP25R5BNAPS4A T2HS25F5BPNAPS083A
S400CF / S400NF S400GF / S400PF S400CJ / S400NJ S400GJ / S630CE					T2HB40UR3BNB	T2HP40R5BNAPS4A T2HS40F5BPNAPS143A
S800NF / S800RF S800NJ / S800NE S1000NE					T2HB80UR3BNA	T2HP80R T2HS80F5BPNAPS143A
S1250NE S1600NE					T2HBX6UR3BNA	T2HSX6F5BPNAPS143A

UVT Controller for 2H1941BABK (E100SF):

UXUB0014AK (AC200V~240V)

UXUB0015A(AC380VV~450V)


Extension bar (Attach Bar) for S160SF, S160SCF & E250SF:

T2FB16L3WHB(spread type for 160 AF 3 pole, 3 pcs per pack)

T2FB16L4WHB(spread type for 160 AF 4 pole, 4 pcs per pack)

T2FB25L3WHA(spread type for 250 AF 3 pole, 3 pcs per pack)

T2FB25L4WHA(spread type for 250 AF 4 pole, 4 pcs per pack)

T2HB_LU

T2HB_U

T2HBX6UR3BNA

T2HP

T2HS
